

Oxo salad spinner



Simply press down with the palm of the hand to quickly spin dry salad leaves. Press the other button to stop the spinning instantly.
Comes with a lid to keep your salad fresh.

- 817123

Date d'impression : 09/04/2026