

Shoe horn gripping clamp



This gripping clamp can also be used as a shoehorn to put on shoes without bending down. The clamp holds the shoe firmly in place to make the task easier. ABS and aluminium.

Length : 66 cm.



- 819082