

Telescopic shoehorn



- **Shoe horn with guide to secure the shoe**

This handy shoe horn allows users to put on their shoes without bending down. Possible to choose the length to suit one's needs. It is equipped with a clip to prevent the shoe from moving. Chrome-plated steel and polypropylene.

Length from 54 to 75 cm.



- 819086