

Kettle rocker



A very practical utensil to avoid carrying your kettle or pitcher. Simply place the kettle in the holder and secure it with the velcro strap.

Dimensions: width 21 x depth 26.2 x height. 19 cm high.

Weight 405 g.



- 817296