

## One touch cork screw



Operates without assistance or effort, simply by pressing the green button to unscrew and remove the cap.

Cap cutter included.

Operates with 4 AAA batteries (not included).

- 817102

**Date d'impression : 06/12/2025**