

Electronic billboard



• Write down instructions easily, without paper

Electronic slate used for noting down everything important for people at home. With the simple push of a button (a safety switch keeps the writing in place). The writing can be erased and a new page written as many time as required. It is supplied with a plastic pen and requires a CR2025 button battery (included).

Dimensions: 14.6 x 22.7 x 0.5 cm.

ABS material.





- 819323

Date d'impression : 08/12/2025